
Meridian Administration Tools

Common Services

User guide

Document Number: NT8R03AA (A0650295)

Document Release: Standard 4.00

Date: May 1996

© 1994, 1996

All rights reserved

Printed in the United States of America

Information is subject to change without notice. Northern Telecom reserves the right to make changes in design or components as progress in engineering and manufacturing may warrant. This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC rules, and the radio interference regulations of Industry Canada. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

SL-1 and Meridian 1 are trademarks of Northern Telecom.

Contents

Introduction	1
Overview	1
MAT users	2
Conventions used in this manual	3
System security	3
Windows fundamentals	4
Using a mouse	4
Using windows	5
Manipulate a Window	7
Move a Window	8
Re-Size a Window	8
Iconize a Window	8
Maximize a Window	8
Selecting records	9
Editing information	9
Menus	9
Dialogs	10
Getting Started	13
Installation	25
Release notes	27
Local Area Network Installation	28
Uninstall	29
Next steps	30
Running the MAT system	31

Step 1: Start the MAT system	31
Step 2: Log on to the MAT system	31
Step 3: Enter site information	32
Step 4: Enter user information	32
Step 5: Define access rights	33
Step 6: Run MAT modules and applications	34
Step 7: Logout from the MAT system	34
Step 8: Close the MAT system	34
Configuration Overview	35
Accessing MAT/Site/User Configuration	35
View menu	36
MAT System	36
Sites	37
Users	37
User Site	38
License	38
Exit	38
Options menu	38
Language	38
Help menu	38
System and User Configuration	39
Configuring the MAT System	40
MAT System Configuration menus	41
File menu	41
Edit menu	42
Help menu	43
Configuring Users	44
MAT User Configuration menus	46
File menu	46
Edit menu	46
Help menu	47

Configuring User Sites	47
MAT User Site Configuration menus	51
File menu	51
Edit menu	51
Help menu	52
Site Configuration	53
Configuring MAT Sites	53
Configuring a New Site	55
Opening an Existing Site	56
Editing Site Information	57
Editing the Meridian 1 view	57
Maintenance and Installation Mode	66
Messages	68
Editing the Customer view	70
Editing the Numbering Plan view	71
Editing the Hardware view	73
MAT Site Configuration menus	74
File menu	74
Edit menu	75
View menu	76
Synchronization	76
Scheduling a task	80
Priority	80
Hold Till	80
Date	80
Time	80
Synchronizing	81
Terminal Emulation	83
Overview	83
Features	83
Connecting to a host	84
Terminal Emulation Window	86

File functions	87
Open Site	87
Close Site	88
Open Applications	88
Print Screen	90
Printer Setup	90
Printer Fonts	90
Capture	91
Playback	91
Exit	91
Edit functions	92
Copy	92
Paste	92
Select All	92
SetUp functions	92
Communication	93
Terminal Type	98
SDI Port	98
Terminal Setup	99
National Replacement Character Set	104
Map Keyboard	105
Program Keys	107
Tab Setup	109
Options	110
Status Window	113
Window control	115
Terminal Window	116
Hide/Show Status Window	116
Hide/Show Keys Window	117
Hide/Show Toolbar Window	117
Terminal	117
Connect	117
Disconnect	117
Help	117
Keyboard Mappings	118

Scheduler	123
Accessing the Scheduler	123
How the Scheduler works	125
Scheduler Event Selection	125
Calendar	130
Reports	130
Options	131
Permanent Queues	131
Log Events	131
Confirm Deletes	132
Queue Manager	132
Queue interface	132
 MAT History File	 135
Accessing the MAT History File	135
Browse	136
The Filter menu	138
Select	139
Reset	140
Options	140
Close	140
Reports	141
Maintenance	141
Purge	141
Archive	142
Options	142
Status	142
Monitor	142
Pause	142
 Communications Services	 143
Overview	144
Accessing the Communications Supervisor	144
Server	146

Change Path	146
Status	146
Ports	146
Supervisor Purge	146
Terminal Emulation	147
Script Editor	148
Options	148
Monitor	148
Pause	148
Data Traffic	149
Log Events	149

Appendix A: Minimum PC Requirements (Upgrades & Applications) 151

Appendix B: Script File Summary 153

Common Services scripts	153
Traffic Analysis scripts	154
Call Accounting & Call Tracking scripts	156
Script usage table	159

List of figures

Figure 1	
MAT system components	2
Figure 2	
Typical window	6
Figure 3	
Example MAT configuration	21
Figure 4	
Meridian Administration Tools window	32
Figure 5	
MAT Configuration window	36
Figure 6	
MAT Configuration window	39
Figure 7	
MAT System Configuration window	40
Figure 8	
System Configuration dialog	41
Figure 9	
MAT User Configuration window	44
Figure 10	
MAT User Information dialog	45
Figure 11	
MAT User Site Configuration window	48
Figure 12	
User Site Information dialog	49

Figure 13	
Customer Passwords dialog	50
Figure 14	
MAT Site Configuration window	54
Figure 15	
New Site dialog	55
Figure 16	
Site Configuration window	56
Figure 17	
Meridian 1 Site Configuration dialog	58
Figure 18	
Meridian 1 Communications Parameters dialog	60
Figure 19	
Messages dialog	68
Figure 20	
User Fields Names dialog	69
Figure 21	
MAT Site Configuration window (Customer view)	70
Figure 22	
Customer dialog	70
Figure 23	
Numbering Plan dialog	72
Figure 24	
Hardware Configuration dialog	73
Figure 25	
Synchronization dialog	78
Figure 26	
Terminal Emulation main window	86
Figure 27	
Open Site dialog	87
Figure 28	
Open Application dialog	89

Figure 29	
Communications Parameters dialog	93
Figure 30	
Terminal Setup dialog	99
Figure 31	
Map Keyboard dialog	106
Figure 32	
Program Keys dialog	108
Figure 33	
Options dialog	110
Figure 34	
Status window	113
Figure 35	
Status Window Configuration dialog	114
Figure 36	
Scheduler window	124
Figure 37	
Event Selection dialog	126
Figure 38	
Event Configuration dialog	127
Figure 39	
MAT History File window	136
Figure 40	
Browse window	136
Figure 41	
Filter dialog	139
Figure 42	
Communications Supervisor schematic	145
Figure 43	
Communications Supervisor window	145
Figure 44	
Terminal Emulation window	147

List of tables

Table 1	
Keyboard Mappings - VT Key	118
Table 2	
Keyboard Mappings - VT Action	120
Table 3	
Keyboard Mappings - VT Action Scroll	121
Table A-1	
Hard drive capacity requirements	152
Table B-1	
Script usage table	159